



Yamaha XT660 Pannier Rack

Installation Guide

A qualified, experienced motorcycle technician should install Rockfox products. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. Rockfox takes no responsibility for damages caused by improper installation. All screws, bolts and nuts, including all replacement hardware provided by Rockfox, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used: M6 – 9,6Nm; M8 – 23Nm; M10 – 46Nm. All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque. Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws bolts and nuts.

Tools required: M8 Allen key
13 Spanner

Contents: 1 x Left Side Rack
1 x Right Side Rack
1 x Rear Brace
1 x Pack of bolts

Left Side

Step 1



Remove the seat of the bike

Step 2



Remove the plastic caps.

Then undo the two bolts and remove the handles. As well as the two side plastic covers.

Step 3



Insert the long bolt Through the pannier rack and through the rear frame of the bike as shown in the picture.

Step 4



Fit the middle side bracket to the bike with the supplied bolts, nuts and spacers. As well as the bracket to the pillion pegs with the bolts supplied.

Repeat Step 1 - 4 for the right hand side.

Step 5



Attach the back brace to the pannier racks with the supplied M8 bolt with 2 washers and a nylock nut.

Step 6



Re fit the two side plastic covers as well as the handles to the bike. Remembering to cover the bolt heads with the plastic caps the bike came with.

As a precaution go through all bolts and nuts and tighten as needed.

Final product



Please contact us if any problems occur.

Regards
The Rockfox Team